

TUNER

TU001

8 B11 Ant. PWR 1

9 B12 2 TUNER_3V3

10 B13 -B1(+3.3V) 3 TUNER_SDA

11 B14 4 TUNER_SCL

12 B15 5 IF_N_TU

13 TH6 6 IF_P_TU

14 7 IF_AGC_T

GND_Tuner

IF AGC

