

17MB8X FULL SOFTWARE UPDATE PROCEDURE

1. Copy this file into the empty and formatted USB. There is no need to use any specific folder.
 - upgrade_loader_full.pkg
2. Unplug the 220 cable from the power socket and plug the USB to TV's USB-1 port.
3. Plug 220 cable to power socket and press OK key until the led starts blinking.
4. Sw update starts automatically when the led starts blinking.
5. Sw update is completed after led blink is done.

*Sw version can be controlled from other settings or service menu.

**For MB82 , CI+ Credentials and HDCP keys will be erased with Full SW update. These files must be updated according to procedure again.