

MCR-610 AMP

MCR-610 ONLY

TO PF36-B

- 16. PWM_1
- 15. RESET
- 14. PWM_1A
- 13. S142_SD
- 12. PWM_2
- 11. OTW
- 10. PWM_2+
- 9. SDV
- 8. PWM_3
- 7. +12V_S142
- 6. PWM_3+
- 5. SP_CH
- 4. PWM_4
- 3. SP_CH
- 2. PWM_4+
- 1. GND_A1

WF35-A

TO PF21

TO BN92

TO PF23

SCHEMATIC DIAGRAMS (4/6)
SCH04_AMP

GND LINE POWER+ LINE POWER- LINE ANALOG AUDIO L ANALOG AUDIO R DIGITAL AUDIO SUBWOOFER